


Beolink Active 1636.

What connections are there?

- 1, Connection – Master Link.
- 2, Connection – I.R.Eye.
- 3, Connection – Power Link.
- 4, Connection – PC.



What can you do with it?

Connect loudspeakers in another room and operate them via a beolink 1000/beo4/5/6.

Fits all TVs and audio systems from B&O that have master link connections and works independently of the system itself, so the main system remains off.

Volume controllable via the buttons on the I.R. eye or via the beolink 1000/beo4/5/6

The powerlink has 1 output, it can handle 2 connections via a [powerlink Y-cable](#).

If more than 2 speakers are connected, the powerlink splitter 1 to 5 block will be an option [on this page](#).

You can find the manual for the [beolink Active here](#).

