

Event		Light indicator on Beosound Core
Starting up		Pulsing white
Network standby mode		Dimmed white
Product ready for wireless setup		Pulsing amber
Wi-Fi status	Connected - Good signal strength	Solid white
	Connected - Medium to poor signal strength	Solid amber
	Product is unconfigured	Solid blue
	Network error	Solid blue for 5 min - then dimmed blue
Bluetooth pairing	In progress (only for products which are not set to "Always Open")	Flashing blue
	Successful	Transition from blue to Wi-Fi status (in 2 seconds)
	Pairing failed	Transition from red to network status (in 2 seconds)
Bluetooth active source	For the first 5 min	Solid blue
	Bluetooth source paused	Solid blue
	Changing to other source	Change from blue to network status
	Disconnecting Bluetooth	Change from blue to network status
	Idle after 5 min	Dimmed blue
All other active sources		Network status will be shown
Software updating		Pulsing red
Factory reset triggered		Red - Quick flash once then off
Error	Product/software	Off
	Hardware overheating	